

MANUAL

Electronic circuit breaker
ECONOMY REMOTE



TABLE OF CONTENTS

1 ... ORDER DATA	3
2 .. GENERAL INFORMATION.....	4
2.1 Safety instructions	4
2.2 Qualified personnel	4
2.3 Intended use	4
2.4 Disclaimer.....	4
2.5 Installation	4
3 .. Product description	6
4 .. Tripping characteristic.....	7
5 .. Charging capacitive loads	7
6 .. Operating states, signalling, reactions	9
6.1 Switch-on delays for individual channels.....	9
6.2 ON/OFF and reset" button	10
6.3 Signalling and control contacts S1/S2/S3.....	10
6.4 Functionality of 2-wire communication via S1/S2.....	11
6.5 Communication sequence via S1/S2	11
6.6 Details on signal input S1 (control and RESET).....	12
6.6.1 Description of the pulse pattern.....	13
6.7 Details on signal output S2 (status of the outputs).....	13
6.7.1 Coded pulse sequence for status enquiry, generated by the PLC.....	13
6.7.2 Cyclical pulse after status change, generated by the circuit breaker.....	14
6.7.3 Max. Jitter for data transmission	14
6.8 Details on signal output S3 (Σ for triggered outputs and device fault)	15
7.... Dimensions	16

1. ORDER DATA

The following table shows the ordering data for the circuit breakers.

Table 1: Order numbers

Variant	Input voltage	Output current	Channels
PC-3724-800-0	24 Vdc	2 – 10A	8
PM-3724-400-0	24 Vdc	2 – 10A	4
PM-3724-200-0	24 Vdc	2 – 10A	2

2. GENERAL INFORMATION

2.1 Safety instructions

Please read these warnings and safety instructions carefully before operating the appliance. The appliance may only be installed by specialised and qualified personnel. In the event of malfunctions or damage, switch off the supply voltage immediately and send the device to BLOCK Transformatoren-Elektronik GmbH for inspection. The device does not contain any service parts. If an internal fuse blows, there is most likely an internal defect in the appliance. The data provided is for product description purposes only and should not be construed as guaranteed characteristics in the legal sense.

2.2 Qualified personnel

The product associated with this documentation may only be handled by qualified personnel in accordance with the relevant documentation for the respective task, in particular the safety instructions and warnings contained therein. Qualified personnel can ensure, based on their training and experience, that the use of the described product fulfils all safety requirements as well as the applicable provisions, regulations, standards and laws.

2.3 Intended use

This device is designed for installation in an enclosure and is suitable for use in general electronic devices, such as industrial control systems, office equipment, communication devices or measuring devices. Do not use this device in the control systems of aeroplanes, trains or nuclear facilities where a malfunction could result in serious injury or danger to life.

2.4 Disclaimer

The contents of this publication have been checked with the utmost care to ensure that they correspond to the hardware and software described. Nevertheless, there may be discrepancies between the product and the documentation. Deviations may also occur due to the continuous further development of the product. For this reason, we cannot guarantee complete conformity. Should this documentation contain errors, we reserve the right to make any necessary corrections without prior notice.

2.5 Installation

The installation must be carried out in accordance with local conditions, relevant regulations, national accident prevention regulations and the recognised rules of technology. This electrical equipment is a component intended for installation in electrical systems or machines and fulfils the requirements of the Low Voltage Directive (2014/35/EU). The required minimum distance to neighbouring parts must be maintained in order not to impede cooling!



CAUTION

Switch off the input voltage before carrying out installation, maintenance or modification work and secure it against unintentional restarting.



CAUTION

Do not modify or attempt to repair the appliance. Do not open the device!



CAUTION

Prevent the ingress of foreign objects such as paper clips and metal parts.



CAUTION

Do not operate the appliance in a damp environment or in an environment where condensation or condensation is to be expected.




CAUTION

Do not touch the housing during operation or shortly after switching off. Hot surfaces can cause injuries.


3. Product description

ECONOMY REMOTE circuit-breakers with a thermomagnetic characteristic are an economical alternative to classic miniature circuit-breakers. They guarantee reliable tripping, even with high line resistances, and are ideal for appliance and series machine construction. The electronic circuit breaker splits the load current between several branches and reliably monitors them for overloads and short circuits. The electronics allow short-term current peaks, e.g. due to a high inrush current, while branches with longer overloads are de-energised. This is ensured even on high-impedance lines and in the event of "creeping" short circuits. **The tripping current of each output can be set individually in 6 stages via a higher-level control system (e.g. PLC).** If the tripping current is exceeded, the output is automatically switched off after a defined tripping time and can be switched on again after a short waiting time (thermal relaxation) using a push-button or remote reset. The button is also used to switch the output manually. The status of the output is displayed via a multi-coloured LED.

- Number of available output channels: 2 / 4 / 8
- Adjustable rated current per channel via 2-wire interface
- Reliable switching on of high capacitive loads
- Sequential and load-dependent switching of the channels
- Status enquiry and remote switching of the outputs via 2 lines
- Extended remote transmission of input voltage, set rated currents and current output currents
- Sum signalling contact for simple remote diagnostics
- Push-in direct connection technology
- LED signalling and on/off/reset button per channel



4. Tripping characteristic



The tripping time depends on the level of the overcurrent. In the event of a short circuit, the faulty circuit is reliably switched off within a few milliseconds. The level of the short-circuit current depends on the current limitation of the supplying power supply unit and the line resistance.

5. Charging capacitive loads

The electronic circuit breaker enables particularly high capacitive loads to be switched on. The following experimentally determined capacitances serve as reference values.

Cable cross-section: 0,75mm²

Cable length (outgoing and return line)	Switch-on capacitance [mF] at 22 V input voltage	Switch-on capacitance [mF] at 24 V input voltage	Switch-on capacitance [mF] at 26 V input voltage	Switch-on capacitance [mF] at 28 V input voltage
0	58	48	26,6	13,3
2,5	64,8	61,5	44,8	23,3
5	89,5	83,3	70	58,1
10	156,1	130	94,8	68,1
20	222	>620	130	114,8
40	>620	>620	>620	>620

Cable cross-section: 1,5mm²

Cable length (outgoing and return line)	Switch-on capacitance [mF] at 22 V input voltage	Switch-on capacitance [mF] at 24 V input voltage	Switch-on capacitance [mF] at 26 V input voltage	Switch-on capacitance [mF] at 28 V input voltage
0	58	48	26,6	13,3
2,5	76,6	70	34,8	21,5
5	76,6	50	40	24,8
10	64,8	53,3	53,3	41,5
20	83,3	81,3	89,371,3	109,5
40	306,6	222,8	122,8	112,8

Cable cross-section: 2,5mm²

Cable length (outgoing and return line)	Switch-on capacitance [mF] at 22 V input voltage	Switch-on capacitance [mF] at 24 V input voltage	Switch-on capacitance [mF] at 26 V input voltage	Switch-on capacitance [mF] at 28 V input voltage
0	58	48	26,6	13,3
2,5	79,9	63,3	33,3	18,1
5	63,6	73,3	36,6	23,3
10	70	73,3	46,6	20
20	73	63,3	56,6	50
40	100	91,5	91,5	64,8

All capacities were determined experimentally under nominal load. The tasks are guide values, possible line capacitances depend on the installation situation. The power supply unit must be able to supply the required current without the output voltage dropping below 18V.

6. Operating states, signalling, reactions

Z	Operating status	Output	LED	Signal output S3 (sum signal)	Button is pressed	Signal input S1 (on/off/reset)
0	Module initialisation (1)	Off	Off	0 V	---	---
1	Outputs switched on Function OK	On	Green	24 V	Switch off output Z3	Via bit pattern → Switch off output Z3
2	Output current > Rated current (2)	On	Green flashing	24 V	Switch off output Z3	Via bit pattern → Switch off output Z3
3	Output is switched off manually or via signal input S1 (3)	Off	Red	24 V	Switch on output Z1	Via bit pattern → Switch on output Z1
4	Output is switched off due to an overcurrent thermal expansion is active (4)	Off	Rot flashing	0 V	---	---
5	Output is switched off due to an overcurrent thermal expansion has ended (5)	Off	Flashing red + green	0 V	Switch on output Z3	Long 24V pulse (>0.5s) → Switch on output Z1
6	Device error (defective fuse detected)	Off	Fast flashing red	0 V	---	---

- 1) Once module initialisation is complete, the outputs are switched on depending on the load.
- 2) The output is automatically switched off according to the tripping characteristic.
- 3) The status is saved when the device is switched off.
- 4) After a waiting time (thermal relaxation), transition to operating state Z5. When the appliance is switched off, the remaining waiting time is saved and waited for when it is switched on again. This reliably prevents the switching elements from being overloaded even if the appliance is switched on again immediately.
- 5) The affected output can be switched on again by pressing the button twice or via a pulse (>0.5s) at signal input S1, transition to operating state Z1.

6.1 Switch-on delays for individual channels

The outputs are switched on sequentially after a minimum input voltage (switch-on threshold) is reached. To reduce inrush current peaks, all channels are switched on depending on the load.

The channels are switched on starting with the smallest channel number to be switched on, typically starting with channel 1. The next channel is switched on as soon as the output current of the previous channel is below the set nominal value or the previous output has been switched off, but not before 50 ms.

6.2 ON/OFF and reset" button

A push-button is assigned to each output channel. The current status is displayed via an integrated LED. The button has two functions depending on the operating status:

- Normal operation
If the channel is switched off (button lights up permanently red), it can be switched on by briefly pressing it (button lights up green). Pressing it again switches the output off again.
- Fault mode
If the output channel is switched off due to an overcurrent (button flashes red), it can be switched on again (reset).

Note:

To switch the output back on, the thermal expansion must first be completed (button flashes yellow instead of red). After pressing the button, the output is initially switched off (button lights up red continuously). Pressing it again switches the output on again. (button lights up green continuously).

The outputs are switched on in the delivery state.

6.3 Signalling and control contacts S1/S2/S3

The electronic circuit breaker is equipped with three signalling and control contacts.




Signal contacts S1 (digital input) and S2 (digital output) can be used to read out operationally relevant information from the circuit breaker and to switch any output channels on or off in a targeted manner.

A sum reset (switching back on) of all triggered outputs (outputs not switched off manually) is also possible via signal input S1, provided a 24V high pulse is fed in for at least 0.5 seconds.

The signal output S3 serves as an active 24V collective fault signal and indicates that at least one output has been switched off due to overcurrent. An internal device fault is also signalled by S3.

6.4 Functionality of 2-wire communication via S1/S2

The circuit breaker can be remotely controlled via a higher-level control system (e.g. PLC) using a serial bit pattern at signal input S1. At the same time, the operating and fault statuses, the input voltage applied to the module, the set nominal current and the current flowing in each circuit are made available via the signal output S2.



Diagnostic options via S1/S2:

- Short protocol:** (17 bit data - minimum transmission time 1.2 seconds)
- Operating states** = **On or off per channel**
- Error states** = **Overcurrent or tripped per channel**
- Extended protocol:** (89 bit data - minimum transmission time 6.3 seconds)
- Current input voltage**
- New trigger currents to be set per channel (only with ECONOMY REMOTE)**
- Set nominal currents per channel**
- Current per channel (only applies to BASIC SMART equipment)**

6.5 Communication sequence via S1/S2

- A digital output of the control unit sends the Manchester coding to the circuit breaker via "S1". This encodes which output channel is to be switched on or off. Furthermore, the factory-set tripping current per output can be changed in 6 stages for the **REMOTE** circuit breakers.
- The circuit breaker synchronises itself internally to this and simultaneously sends back the status (on/off and fault status) of all channels via "S2". In addition to the module input voltage, the set tripping current (ACTUAL value) of each circuit can also be queried, see "Extended protocol".
- The data sent back by the circuit breaker is only high/low and not Manchester-coded. The data should be accepted shortly after the edge change (from high to low) of the generated auxiliary clock in order to avoid incorrect signalling due to program runtimes or delays of the I/Os in a PLC.
- Once all 17 or 89 bits for the extended protocol have been successfully received, the circuit breaker sends an 18th or 90th bit as a stop bit. This takes 1.5 clock cycles. The PLC must not send another bit during this time.
- If the fault status in the circuit breaker changes, e.g. after an overcurrent is present at an output, the circuit breaker generates a cyclical pulse at signal output S2. (500 ms high pulse, every 3 seconds) This pulse is sent until the PLC has successfully queried the updated status via a new Manchester-coded telegram.



6.6 Details on signal input S1 (control and RESET)


This 24V signal input is not electrically isolated in relation to the 0V input of the module. This input can be used to switch on all outputs triggered by an overload and to switch individual channels on or off.

Reset (reactivation of triggered channels)

By applying a 24V voltage for longer than 0.5 seconds, all outputs triggered by overload are switched on again sequentially and load-dependently.

Controls

Any outputs can be switched on or off simultaneously using coded pulse patterns. Temporary circuits such as certain lights or auxiliary power circuits can be switched off as required. Furthermore, the factory-set tripping currents can be changed for each output channel.

Function	Action	Reaction	Impuls
Reset	Long pulse > = 500ms	All outputs switched off due to overload are switched on again. Triggered channels are only reactivated after 0V detection. This prevents automatically triggered channels from being switched on again in the event of a continuous signal.	 Switching on all triggered channels
Controls ON/OFF	Coded pulse pattern	Switching non-triggered outputs on and off. Triggered outputs cannot be switched on or off. They must first be acknowledged by a reset pulse.	See description of the pulse pattern below
Controls Trigger currents	Coded pulse pattern	Changing the factory-set trigger currents. Adjustable in 6 levels	See description of the pulse pattern below

6.6.1 Description of the pulse pattern

The pulse pattern consists of 17 or optionally 89 bits, which must be sent as a Manchester code (in accordance with IEEE 802.3). The first bit to be transmitted has the value "0" and serves as the start bit. This is followed by 16 or optionally 88 bits of user data.

The first 8 bits represent the desired on/off status of the individual channels in descending order. A value of "1" switches the corresponding channel on, a value of "0" switches it off. In the following 8 bits, only the first four most significant bits are relevant.

With the circuit breakers in the "ECONOMY REMOTE" version, the factory-set tripping currents per channel can also be changed in 6 stages.

- Bit 7 = "1": the on/off status transmitted in the first 8 bits is accepted by the circuit breaker
- Bit 7 = "0": the on/off status transmitted in the first 8 bits is ignored
- Bit 6 = "1": the extended 89-bit protocol is used, the circuit breaker transmits additional user data or the tripping currents are adjusted.
- Bit 6 = "0": the short 17-bit protocol is used
- Bit 5 = "0": the current input voltage and the output currents are transmitted for all circuit breakers in the "BASIC SMART" configuration.
- Bit 6 to 4 = "1": the tripping current stages (0 to 5) sent from the 4th byte onwards are accepted by the circuit breaker (ECONOMY REMOTE equipment).

1-6A Rated current types = Absolute current values = 1/2/3/4/5/6A

2-10A Rated current types = Absolute current values = 2/3/4/6/8/10A

Example 2-10A types: Level 0 = 2A / Level 1 = 3A / ... / Level 5 = 10A

If a current value of 2A is to be set for channel 2, the value "0" must be sent in the 5th byte.

The following 5 or optionally 77 bits must be set to "0" and serve as a clock signal for the signal output "S2".

Once all 17 or 89 bits have been successfully received, the circuit breaker sends an 18th or 90th bit as a stop bit. This takes 1.5 clock cycles. The PLC must not send another bit during this time. After the pulse pattern has been sent, S1 and S2 are set to low level again.

New pulse patterns on S1 are only permitted after a waiting time of at least 200 ms.

6.7 Details on signal output S2 (status of the outputs)

This 24V signal output is not electrically isolated in relation to the 0V input of the module. This output can be used to query the status of all integrated output channels. The output is short-circuit-proof, the short-circuit current is approx. 25 mA.

6.7.1 Coded pulse sequence for status enquiry, generated by the PLC

If the PLC sends the coded pulse sequence via the signal input S1, the circuit breaker synchronises to the auxiliary clock of the PLC and sends the current on/off and error states via the signal output S2.

Coding of the status bits sent by the circuit breaker

On/off status per channel	Error status per channel	Description of the
0	0	Output channel is switched off manually or via coded pulse pattern on S1
0	1	Output channel is switched off due to an overcurrent
1	0	Output channel is switched on manually or via coded pulse pattern on S1
1	1	Overcurrent (output current > rated current) (duration of the overcurrent is ≥ 1 second)

Note:

The on/off status changes sent by a higher-level control system are only sent back updated by the circuit breaker with the next telegram. If, for example, the status of output channel 3 is changed from "0" to "1" in a telegram, the old status "0" is transmitted in the same telegram. The status of the output channel is only sent updated by the circuit breaker the next time it is requested by the control system.

Extended protocol:

If the extended protocol is used, the set trigger currents or, in the case of the BASIC SMART version, the current flowing currents of each output are transmitted in addition to the module input voltage.

The extended protocol begins with the 3rd byte of the protocol (additional user data) and contains a total of 9 bytes. These are coded with the most significant bit first ("MSB first") and have the following meaning:

- Byte 3: Input voltage: $((\text{transmitted value}) / 16 + 16) \text{ V}$
- Byte 4: Current channel 1: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 5: Current channel 2: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 6: Current channel 3: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 7: Current channel 4: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 8: Current channel 5: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 9: Current channel 6: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 10: Current channel 7: $(\text{transmitted value}) / 16 \text{ A}$
- Byte 11: Current channel 8: $(\text{transmitted value}) / 16 \text{ A}$

6.7.2 Cyclical pulse after status change, generated by the circuit breaker


If the PLC does not perform a cyclical status query, the circuit breaker on S2 generates a cyclical pulse if the error status changes and the status is not queried regularly within the next 3 seconds. The internal fault status changes when at least one output is switched off or overcurrent occurs. This pulse is sent until the PLC has successfully queried the updated status via a new Manchester-coded telegram.



A digital input of the control system must therefore query the signal contact S2 in order to be informed of status changes in the circuit breaker. At the same time, the control system must be programmed to avoid starting a telegram via S1 while a pulse is being generated on S2 by the circuit breaker. It is recommended to evaluate the respective status on S2 before starting to send the telegram or to generate a telegram at least every 3 seconds to query the status.

6.7.3 Max. Jitter for data transmission


The following absolute jitter is permitted depending on the selected clock cycle:




6.8 Details on signal output S3 (Σ for triggered outputs and device fault)

This 24V signal output is not electrically isolated in relation to the 0V input of the module. The sum signal is realised by an "Active High" signal output. If no output has triggered and no internal device defect has been detected, this signal output is "Active High" (+24V). As soon as at least one output channel has triggered or a device defect has been detected, or signal output switches to "Active Low" (0V). This signal output is short-circuit-proof and can be loaded up to max. 20mA.

7. Dimensions



Dimensions 8-channel modules



Dimensions 4/2-channel modules